

Попасть в Web-интерфейс по умолчанию
192.168.88.1



RouterOS v6.45.1

You have connected to a router. Administrative access only. If this device is not in your possession, please contact your local network administrator.

WebFig Login:

Login:

← нажимаем "Login"

Password:



Winbox



Telnet



Graphs



License



Help

active

Wireless

Network Name

Frequency MHz

Band

Country

MAC Address 00:00:00:00:00:00

Use Access List (ACL)

WiFi Password

WPS Accept

Guest Wireless Network

Guest Network

Wireless Clients

MAC Address	In ACL	Last IP	Uptime	Signal Strength

— Signal Strength cur: avg: max:

10. Задаем имя WIFI сети

11. Задаем пароль от WIFI сети
не менее восьми знаков

1. Выбираем "Quick Set"

1.1. Выбираем "Home AP"

Internet

Address Acquisition Static Automatic PPPoE

PPPoE User

PPPoE Password

PPPoE Service Name

PPPoE Status

IP Address

Gateway

MAC Address

Firewall Router

Local Network

IP Address

Netmask

Bridge All LAN Ports

DHCP Server

DHCP Server Range

NAT

UPnP

VPN

VPN Access

VPN Address

System

Password

Confirm Password

2. Выбираем "PPPoE"

3. Логин и пароль для PPPoE

4. ставим галку

5. Задаем шлюз

6. Выбираем маску подсети (24)

7. ставим галку

8. Задаем пул IP адресов локальной сети
(192.168.1.10-192.168.1.255)

9. Ставим галку

12. Меняем пароль
для Router OS

13. Сохраняем настройки.